



USER INSTRUCTIONS

D30 Compact Digital Positioner

FCD PMENIM0030-05-A5 - 12/15

Installation
Operation
Maintenance



Contents

1 Introduction	3
Safety instruction	3
2. Storage	4
General	4
Storage indoors	4
Storage outdoors or for a longer period	4
Storage in a warm place	4
3. Installation	5
Removal of covers	5
Tubing	5
Air supply requirements	5
Mounting	6
Connections	7
Single action positioner, Direct function and Reverse function	8
Double action positioner, Direct function	8
Mounting the positioner on ¼ turn actuators	9
Gauge block	9
Electrical connections	10
Type signs	11
D30 Digital Positioner model code	12
4. Control	13
Menus and pushbuttons	13
Other functions	13
Menu indicator	14
Menus	14
Changing parameter values	14
Menu system, Basic vs Full	15
First start (with calibration sequence) incl. Profibus and Fieldbus	16
Feedback option	20
Basic Menu Read	22
Basic Menu Man/Auto	23
Basic Menu Shift, Full Menu Status	24
Full Menu Setup	25
Full Menu Tuning	27
Full Menu Alarms	28
Expert Calibration and Fact Set	30
Menu tree – graphical overview	31
5. Maintenance/service	32
Disassembling D30	32
Potentiometer	35
Transmitter boards	35
6. Trouble shooting	36
7. Technical data	37
8. Dimensions	39
9. Spare parts	40

1. Introduction

The D30 is a digital positioner designed primarily for controlling modulating valves. The positioner can be used with single or double acting actuators with either rotary or linear movement.

The D30 can be equipped with modules for feedback, limit switches and pressure gauges. Pressure sensors can be installed to offer advanced diagnostics.

The modules can be factory assembled before

delivery or fitted later.

The modules for feedback and limit switches can contain 4-20 mA feedback and one of the following:

- Two mechanical contacts
- Two proximity switches
- Two inductive sensors

See page 12 for more options available



Safety instruction

Read the safety instructions in this manual carefully before using the product. The installation, operation, and maintenance of the product must be done by staff with the necessary training and experience. If any questions arise during installation, contact the supplier/sales office before continuing work.

Warning

The valve can open or close very quickly when in operation and, if handled incorrectly, may cause damages to fingers. There may also be unintentional effects due to it fully opening or shutting off the flow in the process pipe. Please note the following:

- If the input signal fails or is switched off, the valve operates quickly to its default position.
- If the compressed air supply fails or is turned off, rapid movements can occur.
- The valve is not controlled by the input signals when in the Out of Service mode. It will open/close in the event of an internal or external leak.
- If a high value is set for Cut off, fast movements can occur.
- When the valve is controlled in the Manual mode, the valve can operate quickly.
- Incorrect settings can cause self-oscillation, which can lead to damage.

Important

- Always turn off the compressed air supply before removing or disconnecting the air supply connection or the integral filter. Remove or disconnect with care as air connection "C-" is still under pressure even after the air supply is turned off.
- Always work in an ESD (Emergency Shutdown) protected area when servicing the Printed circuit boards (PCB's). Make sure the input signal is switched off.
- The air supply must be free from moisture, water, oil and particles according to DIN/ISO 8573-1-2001 3.2.3.

2. Storage

General

The D30 positioner is a precision instrument. Therefore it is essential that it is handled and stored in the correct way. Always follow the instructions in this IOM!

Note: As soon as the positioner is connected and started, internal air venting will provide protection against corrosion and prevent the ingress of moisture. For this reason, the air supply pressure should always be kept on unless repair/maintenance work of the positioner, actuator or valve equipment is in progress.

Storage indoors

Store the positioner in its original packaging. The storage environment must be clean, dry, and cool (15 to 26°C, 59 to 79°F).

Storage outdoors or for a longer period

If the positioner must be stored outdoors, it is important that all the cover screws are tightened and that all open ports/connections are properly sealed and/or plugged. The red shipping plugs are not intended as a permanent outdoor plug. The unit should be packed with a desiccant (silica gel) in a plastic bag or similar, covered with plastic, and not exposed to sunlight, rain, or snow.

This is also applicable for long-term storage (more than 1 month) and for long transport by sea.

Storage in a warm place

When the positioner is stored - without air supply pressure applied - in a warm place with a high relative humidity and is subjected to daily temperature variations, the air inside the unit will expand and contract.

This means that air from outside the unit may be drawn into the positioner. Depending on the temperature variations, relative humidity, and other factors, condensation and corrosion

3. Installation


Removal of cover

General purpose / Intrinsically safe

Remove cover by first loosening the screw **1** and then the two screws **2**.

To install cover, first tighten the screw **1**, then the two screws **2**.

Tighten to 1.5 Nm ± 15%.



Tubing

It is recommended to use tubes with a minimum inner diameter of Ø 6 mm (¼”).

Air supply requirements

Poor quality air supply is the main cause of problems in pneumatic systems.


The air supply must be free from moisture, water, oil and particles and delivered @ 1.4-8 bar (20-115 psi)

Standard: **DIN/ISO 8573-1-2001 3.2.3**
 Filtered to 5 Micron, dew point -40°C/F
 Oil 1mg/m³ (0,83 ppm by weight)

The air must come from a refrigeration dried supply or be treated in such a way that its dew point is at least 10°C (18°F) below the lowest expected ambient temperature.

To ensure a stable and problem-free air supply, we recommend the installation of a coalescing filter/regulator <5µ as close to the positioner as possible.

Before the air supply is connected to the positioner, we recommend the hose is opened freely for 2 to 3 minutes to allow any contamination to be blown out. Direct the air jet into a large paper bag to trap any water, oil, or other foreign materials. If this indicates that the air system is contaminated, it should be properly cleaned before continuing.



WARNING! Do not direct the open air jet towards people or objects because it may cause personal injury or damage.

Mounting


Note: If the positioner is installed in a hazardous environment, it must be of a type approved for this purpose.

All versions of the D30 positioner have an ISO F05 footprint. The holes are used to attach the D30 to the mounting bracket B. Please contact PMV or your local distributor representative with actuator specifics for the proper mounting bracket and hardware.

The spindle shaft adapter C can be changed to suit the actuator in question.


It is important that the positioner's spindle shaft and the lever arms, that transfer the actuator movements, are correctly mounted. Any tension between these parts can cause incorrect operation and abnormal wear.

Spindle shafts



NOTE: There are many spindle options available depending on the actuator. Please contact your local PMV supplier for all options available.

Assembly examples



Rotary movement

Linear movement

Connections

Air:

Port S Supply air, 1.4-8 bar (20-115 psi)

Port C+ Connection to actuator, opening

Port C- Connection to actuator, closing
(only for double action)

Plug for single action, see below

Electrical connection

See page 10.

Dimensions

Air connections:


¼" NPT alt. G ¼"

Electrical connection:

M20 x 1.5 alt. NPT ½"

Loctite 577 or equivalent is recommended as a sealant.

Must be plugged when converting to single action function.



External air Connection


For data on air and electrical connections, see section Technical Data on page 37/38.

Rotary actuators VDI/VDE 3485 (Namur)

Fit bracket on actuator and secure with 4 x screws.

Mount positioner to bracket. Secure with 4 x M6 screws using 2.5 Nm (1.8 lb ft) torque.


Install tubing between actuator and positioner.



Single acting positioner, Direct function

Actuator with closing spring


When the control signal increases, the pressure C+ to the actuator is **increased**. The valve stem moves upward and rotates the positioner spindle **counter-clockwise**. When the control signal drops to zero, C+ is vented and the valve closes.



Reverse function

Actuator with opening spring

When the control signal increases the pressure C+ to the actuator is **increased**. The valve stem moves downward and the positioner spindle rotates **clockwise**. When the control signal drops to zero, C+ is vented and the valve opens.




Double acting positioner,

Direct function


Double acting actuator

When the control signal increases, the pressure C+ to the actuator is increased. The valve stem is pressed upward and rotates the positioner spindle counter-clockwise. When the control signal is reduced, the pressure C- to the actuator increases and the valve spindle is pressed downward. If the control signal disappears, the pressure goes to C-, C+ vents, and the valve closes.



Mounting the positioner

After first attaching the correct mounting bracket (not included) to the actuator, mount the positioner to the bracket using 4 each M6 bolts using 2.5 Nm (1.8 lb ft) torque. Ensure the positioner spindle is correctly aligned with the actuator shaft.



Supply air should meet requirements specified on page 5. A coalescing filter/regulator should be installed in front of the supply air connection. Now connect the air supply to the filter, which is connected to the D30 positioner.

Gauge block

Gauge blocks are available for D30s with 1/4" G or 1/4" NPT air connections. To install, ensure seals are aligned, then use 3 Nm (2.2 lb ft) of torque when fastening the gauge block to the positioner using the two screws supplied with the kit.



Electrical connections

Terminal block diagram for the D30.

The terminal block (right) for the positioner is accessible when the aluminum cover is removed.


The D30 digital positioner has been designed to operate correctly in electromagnetic (EM) fields found in typical industrial environments. Care should be taken to prevent the positioner from being used in environments with excessively high EM field strengths (greater than 10 V/m). Portable EM devices such as hand-held two-way radios should not be used within 30 cm of the device.

Ensure proper wiring and shielding techniques of the control lines, and route control lines away from electro-magnetic sources that may cause unwanted noise.

An electromagnetic line filter can be used to further eliminate noise.

In the event of a severe electrostatic discharge near the positioner, the device should be inspected to ensure correct operability. It may be necessary to recalibrate the D30 positioner to restore operation.

D30, 10 terminals




1. Input signal 4 - 20mA +.
2. Input signal 4 - 20mA -.
3. Switch 1 NO/Remote.
4. Switch 1 NC/Remote.
5. Switch 1 COM/Remote.
6. Switch 2 NO.
7. Switch 2 NC.
8. Switch 2 COM.
9. 4 - 20mA + Feedback, 13-28 V DC.
10. 4 - 20mA - Feedback, 13-28 V DC.



Warning! In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

Type sign example



D30 Digital Positioner model code

A =	Model No.	
	D 30	Full LCD menu, LED status
B =	Approvals / Certificate	
	D	General purpose version
C =	Air relay	
	H	High Flow Spool Valve
D =	Connections Threads	
	G	¼" G air, M20 x 1,5 electrical
	M	¼" NPT air, M20 x 1,5 electrical
	N	¼" NPT air, 1/2" NPT electrical
E =	Connections Qty and Aux	
	2	2 Electrical conduits
	T	2 Electrical conduits, threaded aux. ventilation
F =	Housing material / Surface treatment	
	U	Aluminum / Powder epoxy, black
G =	Spindle / Mounting Options	
	09	Double D type, adaptor spindle
	21	NAF Turnex including Mounting bracket
	23	VDI/VDE 3845 rotary, Mounting kit not included
	30	Adaptor spindle, select between 01/06/26/30/36
	39	IEC 534-6, Flat D type, nut incl. Mounting kit not included
H =	Cover / Indicator	
	P V A	PMV, Black cover, Arrow indicator
	P V D	PMV, Black cover, Dome indicator
	F W A	Flowserve, White cover, Arrow indicator
	F W D	Flowserve, White cover, Dome indicator
I =	Temperature Range	
	U	-40°C to 80°C (-40°F to 176°F)
J =	Input signal / Protocol	
	4	4-20 mA / none
	5	4-20 mA / HART
K =	Feedback option / Switches	
	X	No feedback option
	T	4-20 mA transmitter only
	S	Limit switches Mechanical SPDT
	N	Namur V3 type sensor, P+F NJ2-V3-N
	P	Limit switches Proximity SPDT
	4	Slot type Namur sensor, P+F SJ2-S1N
	5	Slot type Namur sensor, P+F SJ2-SN
	6	Slot type Namur sensor, P+F SJ2-N
L =	Options / Add-in electronics	
	0	Standard diagnostics
M =	Accessories	
	X	No accessories
	M	Gauge block ¼" G (3 gauges included / SST, Brass)
	N	Gauge block ¼" NPT (3 gauges included / SST, Brass)
N =	Special Options	
	N	No special options
	S	Exhaust silencers


A A A B C D E - F G G H H H - I J K L M N

* Contact PMV for additional versions

4. Control

Menus and pushbuttons

The positioner is controlled using the five pushbuttons and the display, which are accessible when the aluminum cover is removed. For normal functioning, the display shows the current value. Press the ESC button for two seconds to display the main menu.

Use the pushbuttons  to browse through the main menu and the sub-menus.

The main menu is divided up into a basic menu and a full menu, see page 15.

Other functions

ESC

Exit the menu without making any changes (as long as any changes have not been confirmed with OK).

FUNC

To select function and change parameters.

OK

To confirm selection or change of parameters.

MENU INDICATOR


Displays the position of the current menu row in the menu.

IN SERVICE

The positioner is following the input signal. This is the normal status when the positioner is working.

OUT OF SERVICE

The positioner is not following the input signal. Critical parameters can be changed.



MANUAL

The positioner can be stroked manually using the pushbuttons. See section “Man/Auto”, page 23.

UNPROTECTED

Most of the parameters can be changed when the positioner is in the “Unprotected” position. However, critical parameters are locked when the positioner is in the “In service” position.

LED BLINK CODES

LED color (R = red, Y = yellow, G = green)		
Codes during In Service:		
	R	Actual valve position deviates from requested/set position
	G Y	Fully open/closed valve using Cut Off (=OK)
	G	Controlling valve position (=OK)
Calibration alarms:		
	R G	No feedback movement. Check linkage from actuator to positioner.
	R Y	No air available. If air relay doesn't work, check black/red cable inside.
	R G G	No pot connection. Check pot cable inside positioner.
	R Y Y	No air relay sensor. Check yellow/black/red cable inside positioner.
	R Y G	Pot not calibrated. Calibrate->ExpertCal->Pot.
	R R Y	Air relay problem. Replace it (located below positioner motherboard).

Menu indicator


There are indicators at both sides of the display window and they indicate as follows:

Flashing in position **Out of service**

Flashing in position **Manual**

Displayed in position **Unprotected**

The indicators on the right-hand side show the position in the current menu.



Menus

To display the menus you can select:

- **Basic menu**, which means you can browse through four different menu items
- **Full menu**, which comprises ten steps. Use the Shift Menu to browse through the menu items

Full Menu can be locked out using a passcode.

The main menus are shown on the next page and the sub-menus on the subsequent pages.


Changing parameter values

Change by pressing until the desired figure is flashing.

Press to step to the desired figure. Confirm by pressing OK.

A change can be undone by pressing the **ESC** button, which returns you to the previous menu.

Menu system



The menus are described on the following pages.

BASIC MENU
CALIBRATE

→

First start

“Calibrate” is displayed in the basic menu automatically, the first time power is applied. It can be selected from the basic or full menu at any time.

A complete auto-calibration takes up to 10 minutes depending on size of actuator and includes end limit calibration (zero and span), auto-tuning (dynamically sets the control parameters for the actuated package the positioner is controlling) and a check of the movement speed. Start the automatic calibration by selecting **Auto-Cal** and then answer the questions in the display by pressing **OK** or the respective arrow. More detail about these questions can be found on page 19.

Calibration error messages

If a fault occurs during calibration, one of the following error messages can be displayed:

No movement/press ESC to abort

Typically the result of an air delivery issue to the actuator, a stuck valve or actuator, or incorrect mounting and/or linkage arrangement. Check for proper supply air to the positioner, pinched tubing, proper actuator sizing, proper linkage and mounting arrangement.

Pot uncalibrated/press ESC to abort

The potentiometer is out of range. The potentiometer is aligned using the Calibrate - Expert cal - pot Menu. The calibration sequence must be restarted after the fault is corrected.

Tip! Instant quick calibration

The D30 can be instantly calibrated by pressing the top + bottom buttons for 5 seconds (see picture). This function is available from any menu position.

First start, Profibus PA

For Profibus PA, connect the input signal at pos 1 and 2 on the terminal block. See Electrical connections in the manual.

In the SETUP/Devicedata/Profibus: change the address from 126 to any number between 1-125.

Never use the same number with more than one unit. Install values in failsafe mode, for communication when loss of signal.

Calibrate the unit.

GSD files are available at our web-page www.pmv.nu

To install the D30_PROFIBUS.DDL file to Siemens SIMATIC PDM.

1. Move the files to the directory where the DeviceInstall.exe is located.
2. Run DeviceInstall.exe

For Expert Calibration parameters - see page 30!

For further information on calibrating the pot - see page 35



Instant quick calibration

Parameter		Description	BYTE
SP	Setpoint	The SP has 5 bytes, 4 bytes for the float value and one status byte. The status byte needs to be 128 (0x80Hex) or higher for the D30 to accept it.	4+1=5
READBACK	Position	The READBACK has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5
POS_D	Digital position	Returns actual position as a digital value with definitions as below 0 = Not initialized 1 = Closed 2 = Opened 3 = Intermediate	2
CHECKBACK		Detailed information of the device, coded bit wise. Several messages can occur at the same time.	3
RCAS_IN	Remote Cascade	The RCAS_IN has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5
RCAS_OUT	Remote Cascade	The RCAS_OUT has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5

Status Byte Table

MSB		LSB	Meaning	D30 info					
0	0	0	0	1	0	x	x	Not connected	
0	0	0	0	1	1	x	x	Device failure	PROFibus PA module failure
0	0	0	1	0	0	x	x	Sensor failure	No sensor value
0	0	0	1	1	1	x	x	Out of service	AI Function Block in O/S mode
1	0	0	0	0	0	x	x	Good - Non cascade	Measured value OK All Alarm values used
1	0	0	0	0	0	0	0	OK	
1	0	0	0	1	0	0	1	Below low limit Lo	Advisory alarm
1	0	0	0	1	0	1	1	Above high limit Hi	Advisory alarm
1	0	0	0	1	1	0	1	Lo-Lo	Critical alarm
1	0	0	0	1	1	1	1	Hi-Hi	Critical alarm

Example SP = 43.7% and 50%

Float	Hex	Status
43.7	42 2E CC CD	80
50.0	42 48 00 00	80

(FF) Foundation Fieldbus function blocks

Function blocks are sets of data sorted by function and use. They can be connected to each other to solve a control process, or to a controlling DCS. To get a good introduction and understanding of FF look at www.fieldbus.org and download the “Technical Overview” from the About FF pages.

(TB) Transducer Block

The TB contains unit specific data. Most of the parameters are the same as parameters found on the display. The data and the order of data varies between different products. The AO-block setpoint (SP) and process value (PV) parameters are transceived to the TB through a channel. The TB has to be in AUTO for the AO-block to be in AUTO.

The positioner has to be in menu-auto mode and in service to be controlled from the fieldbus.

If the positioner is placed in menu-manual mode then the transducer block will be forced to (LO) local override. In this way a person in the field will be able to control the positioner from the keypad, without collision with a control loop.


(RB) Resource Block

The RB is a set of parameters that looks the same for all units and products. The values of the RB define unit information that concerns the Fieldbus Protocol such as MANUFAC_ID which informs the unique manufacturer id. For Flowserve it is 0x464C53. The RB has to be in AUTO for the AO-block to be in AUTO.

(AO) Analogue Output Block

The AO follows Fieldbus Foundation’s standard on content and action. It is used for transferring (SP) setpoints from the bus to the positioner.

AO-block overview



CAS_IN (cascade input) and RCAS_IN (remote cascade input) are selected as inputs to the AO block depending on the MODE_BLK parameter. The selected input will be relayed to the SP parameter of the AO block. BKCAL_OUT (back calculated output) is a calculated output that can be sent back to a controlling object so that control bumps can be avoided. Usually the BKCAL_OUT is set to be the (PV) process value of the AO-block, i.e. the actual measured position of the valve.

OUT is the primary calculated output of the AO block. During a limited action (ramping) of the AO block the RCAS_OUT parameter will supply the final setpoint and the OUT parameter will be the limited output.

The transducer block is connected through a channel to the AO block. Through this channel the OUT value and SP are transceived.


In order to set the AO block to AUTO, the TB and the RB have to be in AUTO. Further the AO block has to be scheduled. Using National Instruments Configurator; scheduling can be done by adding the unit to a project and then click on the “upload to device” icon.

To write a setpoint value by hand, add Man to MODE->Permitted parameter, and then choose MODE->Target to Man. Make sure that the unit is scheduled.

Example

A typical FF block loop control might look like the following:

Where the positioner is represented by the AO-block.






The contents of the menu are shown on the next page. The various menu texts are described below.

Auto-Cal

Auto-tuning and calibration of end positions

Start tune

Starts the tuning. Questions/commands are displayed during calibration. Select the type of movement, function, etc. with  and confirm with **OK** as shown in the chart on the next page.

Lose prev value? OK?

A warning that the value set previously will be lost (not during the first auto-tuning).

Direction? Air-to-open.
Direction? Air-to-close.

Select for direct function.
Select for reverse function.

In service? Press OK

Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

TravelCal

Calibration of end positions

Start cal

Start end position calibration.

Lose prev value? OK?

A warning that the previously set value will be lost. Confirm with OK.

The calibration sequence starts.

In service? Press OK

Calibration finished. Press OK to start positioner functioning. (If ESC is pressed, the positioner assumes the "Out of service" position but the calibration is retained).

Perform

Setting gain

Normal


100% gain

**Perform G, F, E D,
C, B, A**

Possibility to select a lower gain in steps.

Note. Original P. I. D. will always be shown in display

Feedback option



When installing the transmitter/switch card, make sure it is placed correctly over the connector pins before gently pushing it down until it rests on the supports. Secure the PC board with the two screws. Make sure the holes are centred before tightening the screws.

Note! When installing the cam assembly for mechanical switches, retract both switch arms first.


Install the cam assembly and tighten the screws loosely to obtain enough friction to lock the cams.

Adjust the lower cam first, then the upper cam.


Feedback option (cont.)

Calibration of the 4-20 mA transmitter


Go to menu shown in diagram.
 Connect mA meter I and check reading.
 Adjust output signal using Up or Down key
 until meter I reads 4.00 mA.
 Finish by pressing OK.
 Repeat the above for 20 mA.



Connecting the switches/sensors



Note: Technical data of switches and transmitter – please see page 38




The menu contents are shown in the figures on the right and the texts are described below:



Current values can be read using the Read Menu and some values can be reset.

- Pos** Shows current position
- Set&pos** Set point and position
- Set&dev** Set point and deviation
- Pos graph** Shows position graph
- Temp** Shows current temperature
- Statistics**
- n cycles** Shows number of cycles.
1 cycle = [move of valve +change direction+move opposite direction] regardless of size of each move/stroke.
- Acc travel** Travel = [accumulated % valve has moved/100].
Example: move 60% up + move 40% down => Acc travel = 1
- mean dev** Shows accumulated deviation in %
- m. abs dev** Shows accumulated absolute deviation in %
- # of resets** Shows number of resets
- runtime** Shows accumulated runtime since last reset
- Extr temp** Shows extreme min and max temperature
- Histogram** Shows position and time for position value
- Alarms** Displays tripped alarms





The Man/Auto menu is used to change between manual and automatic modes.

The menu contents are shown in the figures on the right and the various texts are described below:



AUT, OK = MAN

Positioner in automatic mode

MAN, OK = AUT

Positioner in manual mode

When changing between **MAN** and **AUT** mode, the **OK** button must be pressed for 3 seconds.


In the **MAN** mode, the value of POS can be changed using . The push-buttons increase/decrease the value in steps. The value can also be changed in the same way as for the other parameter values, as described on page 14

Other functions

C+ can be fully opened by pressing and then immediately OK simultaneously.


C- can be fully opened by pressing and OK simultaneously.

C+ and C- can be fully opened for blowing clean by pressing and OK simultaneously.



The Shift Menu is used to choose between the basic menu and the full menu.


The menu contents are shown in the figures on the right and the various texts are described below:



No Full menu selected.


Yes Basic menu selected.

The Menu can be locked with a passcode, see Setup menu.



The Status Menu is used to select whether or not the positioner is in service.

The menu contents are shown in the figures on the right and the various texts are described below:



o o service Not in service. Flashing indicator in upper left-hand corner of display.

in service Positioner in service. Critical parameters cannot be changed.

When changing between **In service** and **Out of service**, the **OK** button must be pressed for 3 seconds.



The Setup Menu is used for various settings.

The menu contents are shown in the chart on the next page and the various texts are described below:

<u>Actuator</u>	<u>Type of actuator</u>	<u>Size of actuator</u>	<u>Time out</u>
Rotating	Rotating actuator.	Small	10 s
Linear	Linear actuator.	Medium	25 s
		Large	60 s
		Extra large	180 s

- Lever** Only for linear actuator.
- Lever stroke** Stroke length to achieve correct display. Input only needed in case display value is off
- Level cal** Calibration of positions to achieve correct display.

- Direction**
- Direct** Direct function (signal increase opens). Indicator/spindle rotates counter-clock wise.
- Reverse** Reverse function.

Character Curves that show position as a function of input signal.


- Linear**
 - Equal %**
 - Quick open**
 - Sqr root**
 - Custom**
- } See diagram.
Create own curve.

- Cust chr**
- # of point** Specify number of points (3, 5, 9, 17, or 33)
- Cust curve** Enter values on X and Y axes.

Curr range (Use this function to split range)

- 0%=4.0 mA**
- 100%=20.0 mA**

Possibility of selecting which input signal values will correspond to 0% and 100% movement respectively. Examples of settings:
4 mA = 0%, 12 mA = 100%, 12 mA = 0%, 20 mA = 100%.



TRVL range
0%=0.0%

Set 0%

100%=100.0%

Set 100%

Setting end positions
Select Out of Service. Set percentage value for desired end position (e.g. 3%).
Select In Service. Connect calibrator. Move forward to desired end position (0%) and press OK.

Select Out of Service. Set percentage value for desired end position (e.g. 97%).
Select In Service. Connect calibrator. Move forward to desired end position (100%) and press OK.

Trvl ctrl

Set low

Set high Values

Behavior at set end position
Choose between Free (positioner will control until a mechanical stop is reached), Limit (stop at set end position), and Cut off (Default value. Go directly to a mechanical stop at a predefined setpoint). Similar to Set low. Select position for Cut off and Limit at the respective end positions.

Passcode

Setting passcode for access to the menu

Numbers between 0000 and 9999 can be used as passcodes. 0 = no passcode required.

Appearance Language

On display
Select menu language.

Units
Def. Display

Select units.
Select value(s) to be displayed during service. The display reverts to this value 10 minutes after any change is made.

Start menu
Start in Basic menu or Full menu.

Orient
Orientation of text on display.

Par mode
Display of control parameters such as P, I, D or K, Ti, Td.

Devicedata

HW rew
SW rew
Capability } General parameters.

HART
Menu with HART parameters. Only amendable with HART communicator. It is possible to read from display.

Profibus PA
Status
Device ID
Address
Tag
Descriptor
Date
Failsafe

Indicates present status
Serial number 1-126
Allotted ID
ID description
SW release date
Value = preset pos
Time = Set time +10sec= time before movement
Valve act = failsafe (preset pos) or last value (present pos)
Alarm out= On/Off

Foundation Fieldbus
Device ID
Nod address

Serial number
Address on the bus provided by the DCS system

TAG-PD_TAG
Name provided by the DCS system

Descriptor
Date
Sim jumper

D30 positioner
SW release date
Simulate jumper, FF simulation functionality activated = ON



The menu contents are shown in the chart on the next page and the various texts are described below:

- Close time** Minimum time from fully open to closed.
- Open time** Minimum time from closed to fully open.
- Deadband** Setting deadband. Min. 0.1%.

Expert Control Advanced settings.
See explanations below.

Togglestep Test tool for checking functions. Overlays a square wave on the set value.

Self test Internal test of processor

Undo You can read last 20 changes.

P,I,D and K,Ti,Td parameters

If one of the gains is changed, the corresponding value in the other gain set is changed accordingly.

Spring adjust

The spring adjust function compensates the airflow linearly with the actuator C+ chamber volume (for a constant position error), so that low volumes get less flow. This is needed for linear single-acting actuators, where a low C+ volume means that the actuator spring is extended, its force is reduced, and less flow is needed for stable position changes.

FULL MENU
ALARMS


The menu contents are shown in the chart on the next page and the various texts are described below:

Deviation Alarm generated when deviation occurs
On/Off Alarm on/off.
Distance Allowed distance before alarm is generated.
Time Total deviation time before alarm is generated.
Alarm out Select ON/OFF offers output on terminals.
Valve act Behavior of valve when alarm is generated.

Limit 1 Alarm above/below a certain level.
On/Off Alarm on/off.
Minipos Setting of desired min. position.
Maxpos Setting of desired max. position.
Hysteresis Desired hysteresis.
Alarm on Select ON/OFF offers output on terminals.
Valve act Behavior of valve when alarm is generated.

} See diagram below!

Limit 2 See Limit 1.



Temp On/Off	<u>Alarm based on temperature</u> Temperature alarm on/off.
Low temp	Temperature setting.
High temp	Temperature setting.
Hysteresis	Allowed hysteresis.
Alarm out	Select ON/OFF offers output on terminals.
Valve act	Behavior of valve when alarm is generated.

<u>Valve act</u>	
No action	Alarm generated only. Operations not affected.
Goto open	Valve moves to 100%. Positioner changes to position Manual.
Goto close	Valve moves to 0%. Positioner changes to position Manual.
Manual	Valve stays in unchanged position. Positioner moves to position Manual.

Expert Calibration

When entering “ExpertCal” mode - walk through the list of parameters described below. Set values where applicable. Confirm by pressing OK.

Set point LO: Use the calibrator set to 4 mA (or set another value on the display). Press OK.

Set point HI: Use a calibrator of 20 mA (or set another value on the display). Press OK.

Pressure LO: Use a supply of 1.4 bar (20 psi) (or set another value on the display). Press OK. Pressure read out only possible on D30 with built in pressure sensor.

Pressure HI: Use a supply of 8 bar (115 psi) (or set another value on the display). Press OK. Pressure read out only possible on D30 with built in pressure sensor.

Transmitter: Connect 10 - 28 VDC. Connect an external mA meter to the loop. Read low value on mA meter and adjust with up/down key. Press OK to set low value. Repeat procedure to set High value. Also see video on www.pmv.nu


Pot: Potentiometer setting, see section 8. Also see video on www.pmv.nu

Full reset: Resets all set values and enters Factory mode. To reset the values only, use FACT SET in main menu, see below.



The menu contents are shown in the chart below.

The default values that were set on delivery can be reset using the Fact Set menu. Values from calibration and from other settings will then be lost.



READ			pos		n cycles
MAN/AUTO	AUT,OK=MAN	MAN,OK=AUT	set&pos		acc travel
CALIBRATE	AutoCal		set&dev		mean dev
	TravelCal		Pos Graph		m. abs dev
	Balance		Pressure**		runtime
	Perform		C+ & C--		# of reset
SHIFT MENU	Expert cal		temp		extr temp
	Basic menu	Setpoint	statistics		histogram
		Pressure**	alarms		reset stat
Full menu	Transm.				
	Pot				
STATUS	O O SERVIC				
	IN SERVICE				
SETUP	Actuator				
	rotating				
	linear				
	Type		double act		small
	Function		single act		medium
	Size				large
					Extra large
Lever (*)	Stroke				
Lever cal					
AirToOpen					
AirToClose					
Direction					
Character					
					linear
Cust chr	#of points	X0=			equal %
Cust curve	Y0=				quick open
Curr range	0% =				custom
100% =					sq root
Trvl range					
0% =					
100% =					
Trvl ctrl	Set low	free	Cutoff Low		
Set high	cutoff		Cutoff Hi		
Values	limited		Limit Low		
Limit Hi			Limit Hi		
Direction					direct
reverse					
Transm.					
pos/set					Position
Set point					
Passcode	Old	New 0=Off			
Trans. Card					
D3-81					
D3-38					
Appearance	Language	English			
Svenska					
Deutsch					
Français					
Italiano					
Español					
Chinese					
Portuguese					
percent					
mA					
mm					
cm					
inch					
degrees					
inch					
degrees					
bar					
psi					
kPa					
Grad C					
Grad F					
Kelvin					
Def. Displ					
Start menu					
pos					
set&pos					
set&dev					
menu					
Start Logo	On/off				
last value					
basic					
full					
Orient.	normal				
flipped					
Devedata					
HW rev					
SW rev					
Capability					
Hart					
Message					
Tag					
Descriptor					
Date					
Device ID					
Poll adr					
Assemblyno					
Univ cmd					
Spec cmd					
Burst					
On/off					
Pos (PV)					
Set (SV)					
4 Dynamic					
Burst Mode					
ALARMS	Deviation				
On/off					
Distance					
Time					
Alarm out					
Valve act					
Limit 1	On/off				
Minpos					
Limit 2					
Maxpos					
Hysteresis					
Alarm out					
Valve act					
Temp					
On/off					
Low temp					
High temp					
Hysteresis					
Alarm out					
Valve act					
no action					
goto open					
goto close					
manual					
FACT SET	yes				

(*) appear if Linear set
 (**) appear if pressure sensor exist
 (x) Position is show in upper row (PID, KTiTd)

5. Maintenance/service

When carrying out service, replacing a circuit board, etc., it may be necessary to remove and refit various parts of the positioner. This is described on the following pages.

Read the Safety Instructions on page 3 and 4 before starting work on the positioner.

Cleanliness is essential when working with the positioner. Contamination in the air ducts will inevitably lead to operational disturbances. Do not disassemble the unit more than that described here.

DO NOT take the valve block apart because its function will be impaired.

When working with the D30 positioner, the work place must be equipped with ESD protection before the work is started.



Always turn off the air and electrical supplies before starting any work.



Please see section for special conditions for safe use and spare parts on page 5!



Please contact a Flowserve office for information regarding proper procedures.

www.pmv.nu or infopmv@flowserve.com

Disassembling D30

Removing cover and inner cover

- Unscrew the screws A and remove the cover. When mounting cover – see page 5.
- Pull off the arrow pointer, B.
- Unscrew the screws C and remove the inner cover.




Circuit boards (PCB)



Disconnect or switch off the electric power supply before starting any work.

To lift off the display PCB, first unscrew the two screws A. Release the cable connections. Unscrew the three screws B and lift up the circuit board.



Valve block




Turn off the air and electric power supply before starting any work.

- Remove the three screws A and lift out the valve block

N.B. Do not disassemble the valve block


- When installing the valve block — torque the three screws to 0,4 Nm and seal with Loctite® 222.



Pressure sensors

Three pressure sensors are available as an option. They indicate pressure for supply, C- and C+ air, and can be used by ValveSight™ to enable advanced valve diagnostics.

The sensors are mounted on a circuit board which mounts next to the air relay on the floor of the housing at B using three screws.



Pressure sensor PCB - top view



Pressure sensor PCB - bottom view

Potentiometer

90° spring loaded potentiometer

The spring-loaded potentiometer can be removed from the gearwheel for calibration or replacement.

If the potentiometer is replaced or the setting is changed, it must be calibrated.


- Select the menu Calibrate - Expert - Cal pot. The display shows Set gear.
- Turn the spindle shaft clockwise to end position and press OK. Either turn manually or use the up/down arrows (with supply air) to stroke the positioner to turn the shaft clockwise (see Manual mode page 23).
- Unmesh the potentiometer and turn it according to display until OK is shown. Press OK. See diagrams below.
- Re-align spring on potentiometer to secure it. See diagrams below.

Transmitter boards


The equipment for transmitter feedback consists of a circuit board, cam assembly and screws.

General PCB versions:


- with mechanical switches, SPDT
- with NAMUR sensors, DIN 19234
- with proximity switches
- with feedback transmitter and/or remote only



Turn the end of the stop spring clockwise until it is clear from the housing wall.



Turn the potentiometer away from the shaft gear and adjust the potentiometer gear. Release the potentiometer to let the gear teeth engage again.



Turn the end of the stop spring counter clockwise until it points towards the housing wall.

6. Trouble shooting

Symptom	Action
Input signal change to positioner does not affect actuator position.	<ul style="list-style-type: none"> • Check air supply pressure, air cleanliness, and connection between positioner and actuator. • Out of service, in manual mode. • Check input signal to positioner. • Check mounting and connections of positioner and actuator.
Change in input signal to positioner makes actuator move to its end position.	<ul style="list-style-type: none"> • Check input signal. • Check mounting and connections of positioner and actuator.
Inaccurate control.	<ul style="list-style-type: none"> • Perform Auto-calibration and check for any leaks. • Uneven air supply pressure. • Uneven input signal. • Wrong size of actuator being used. • High friction in actuator/valve package. • Excess play in actuator/valve package. • Excess play in mounting of positioner on actuator. • Dirty/humid supply air.
Slow movements, unstable regulation.	<ul style="list-style-type: none"> • Implement auto-tuning. • Increase the deadband (Tuning menu). • Adjust Performance (Calibrate menu).

7. Technical data

Rotation angle	min 2.5° max 100°
Stroke	From 5 mm (0.2")
Input signal	4-20 mA DC
Air supply	1.4-8 bar (20-115 psi) DIN/ISO 8573-1 3.2.3 Free from oil, water and moisture.
Air delivery	Up to 760 nl/min @ 6 bar (29.3 scfm @ 87 psi)
Air consumption	8 nl/min @ 6 bar (0.31 scfm @ 87 psi)
Air connections	¼" G or NPT
Cable entry	2x M20x1.5 or ½" NPT
Electrical connections	Screw terminals 2.5 mm ² /AWG14
Linearity	<0.4%
Repeatability	<0.5%
Hysteresis	<0.3%
Dead band	0.1-10% adjustable
Display	Graphic, view area 15 x 41 mm (0.6 x 1.6")
UI	5 push buttons
CE directives	93/68EEC, 89/336/EEC, 92 /31/EEC
Voltage drop, w/o HART	8 V
Voltage drop, with HART	9.4 V
Vibrations	< 0.25% FS 10-500 Hz 2g max
Enclosure	IP66
Material	Die-cast Aluminum
Surface treatment	Powder epoxy
Temperature range	-40°C to +80°C (-40°F to 176°F)
Weight	1.8 kg (4 lbs)
Mounting position	Any
Communication protocols	Hart Profibus PA Foundation Fieldbus

Mechanical switches	
Type	SPDT
Size	Sub miniature
Rating	3 A/125 VAC / 2 A/30 VDC
Temperature range	-30°C to 80°C (-22°F to 180°F)






NAMUR sensors	
(NJ2-V3-N)	
Type	Proximity DIN EN 60947-5-6:2000
Load current	$1 \text{ mA} \leq I \leq 3 \text{ mA}$
Voltage range	8 VDC
Hysteresis	0.2%
Temperature range	-25°C to 85°C (-13°F to 185°F)

Proximity switches	
Type	SPDT
Rating	0.4 A @ 24 VDC, Max 10 W
Operating time	Max 1.0 ms
Max voltage	200 VDC
Contact resistance	0.2 Ω
Temperature range	-30°C to 80°C (-22°F to 180°F)

Slot NAMUR switches	
(SJ2-S1N, SJ2-SN, SJ2-N)	
Type	Proximity DIN EN 60947-5-6:2000
Load current	$1 \text{ mA} \leq I \leq 3 \text{ mA}$
Voltage	8 VDC
Hysteresis	0.2%
Temperature range	-25°C to 85°C (-13°F to 185°F)

4-20 mA transmitter	
Supply	11-28 VDC
Output	4-20 mA
Resolution	0.1%
Linearity full span	+/-0.5%
Output current limit	30 mA DC
Load impedance	800 Ω @ 24 VDC

8. Dimensions



9. Spare parts

No	Part no	Description
1	D4-SP37PVA	Black cover incl. screws and flat indicator
1	D4-SP37PVD	Black cover incl. screws and dome indicator
1	D4-SP37FWA	White cover incl. screws and flat indicator
1	D4-SP37FWD	White cover incl. screws and dome indicator
2	D4-SP40	Internal cover incl. screws
3	D4-SP1516	External covers SST, 2, incl screws
4	3-SXX	Spindle adaptor (XX = 01, 02, 06, 26, 30, 36)
5	D4-SP05-09	S09 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-21	S21 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-23	S23 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-39	S39 shaft compl. incl. gear wheel, friction clutch, spring
6	D4-SP400	Air relay complete, incl. cable, seal, screws
7	D4-SP08	Potentiometer compl. incl. spring, bracket, cable
8	3-SP37HR	PCB LCD assembly
9	D4-SP7-80H	PCB mother board 4-20 mA / HART
9	D4-SP7-80P	PCB mother board Profibus PA
9	D4-SP7-80F	PCB mother board Fieldbus
10	D4-SP84-3	Pressure sensor assembly complete
11	D4-SPGB	Bag with screws, O-rings, seals, pair of sintered brass silencers, cable gland
12	D4-SP940M	Gauge block G, complete incl. screws, seals, 3 gauges / SST, Brass
12	D4-SP940N	Gauge block G, complete incl. screws, seals, 3 gauges / SST, Brass
13	D4-SP45S	Limit switches Mechanical SPDT compl.
13	D4-SP45N	Limit switches Namur V3 P&F NJ2-V3-N compl.
13	D4-SP45P	Limit switches Proximity SPDT compl.
13	D4-SP454	Limit switches Namur slotted P&F SJ2-S1N compl.
13	D4-SP455	Limit switches Namur slotted P&F SJ2-SN compl.
13	D4-SP456	Limit switches Namur slotted P&F SJ2-N compl.

PMV Automation AB

Korta Gatan 9
SE-171 54 SOLNA
SWEDEN
Phone: +46 (0)8-555 106 00
E-mail: infopmv@flowserve.com

PMV USA

14219 Westfair West Drive
Houston, TX 77041, USA
Phone: +1 281 671 9209
Fax: +1 281 671 9268
E-mail: pmvsales@flowserve.com

Flowserve Flow Control

Burrell Road, Haywards Heath
West Sussex RH16 1TL
Phone: +44(0)1444 314400
E-mail: pmvuksales@flowserve.com

Flowserve Flow Control Benelux

Rechtzaad 17
4703 RC Roosendaal
THE NETHERLANDS
Phone: +31 (0) 30 6771946
Fax: +27 (0) 30 6772471
E-mail: fcbinfo@flowserve.com

Flowserve Flow Control GmbH

Rudolf-Plank Strasse 2
D-76275 Ettlingen
GERMANY
Phone: +49 (0) 7243 103 0
Fax: +49 (0) 7243 103 222
E-mail: argus@flowserve.com

Flowserve S.p.a.

Via Praelpi, 30
20032 Cormanò (Milano)
ITALY
Phone: +39 (0) 2 663 251
Fax: +39 (0) 2 615 18 63
E-mail: infoitaly@flowserve.com

Flowserve Corporation

No. 35, Baiyu Road
Suzhou Industrial Park
Suzhou 215021, Jiangsu Province,
PRC
Phone: +86-512-6288-1688
Fax: +86-512-6288-8737

Flowserve (China)

585, Hanwei Plaza
7 Guanghau Road
Beijing, China 100004
Phone: +86 10 6561 1900

Flowserve Pte Ltd

No. 12 Tuas Avenue 20
Singapore 638824
Phone: +65 6879 8900
Fax: +65 6862 4940

Flowserve do Brasil Ltda

Rua Tocantins, 128 - Bairro Nova Gerti
São Caetano do Sul,
São Paulo 09580-130 Brazil
Phone: +5511 4231 6300
Fax: +5511 4231 6329 - 423

To find your local Flowserve representative:

To find your local Flowserve representative please use the Sales
Locator System found at www.flowserve.com30

FCD PMENIM0030-00-A5 12/15

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the (D3 Digital Positioner User Instructions) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

For more information about Flowserve Corporation, contact www.flowserve.com or call USA 1-800-225-6989.

© February 2015, Flowserve Corporation, Irving, Texas